

DIRECTIONS FOR USE

DISH MACHINES: Mix 1 pint of DESCALER to 1 gallon of clear water.

CAUTION: TURN OFF DETERGENT FEEDER. Operate machine in washing cycle until water lime is removed. Drain and refill with hot water and dishwashing detergent and recirculate for 5 minutes.

STEAM TABLES & BAIN MARIES: Use 1 pint **DESCALER** to 1 gallon (180° F) water. Allow to stand until lime is dissolved. Remove sludge and rinse thoroughly.

ROUTINE LIME CONTROL: Once a week, use 1 ounce **DESCALER** to 3 gallons (180°F) water. Allow to stand or circulate until lime is dissolved.

HAZARD STATEMENTS: Causes severe skin burns and eye damage. Causes serious eye damage.

PRECAUTIONARY STATEMENTS: Do not breathe fume, mist, vapors. Wash hands and forearms thoroughly after handling. Wear eye protection, face protection, protective clothing, protective gloves. IF SWALLOWED: rinse mouth. Do NOT induce vomiting. IF ON SKIN (OR HAIR): Take off immediately all contaminated clothing. Rinse skin with water/shower. IF INHALED: Remove person to fresh air and keep comfortable for breathing. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor/physician. Wash contaminated clothing before reuse. Store locked up. Dispose of contents/container in accordance with Local, State, and Federal regulations.

SPECIFICATIONS:

Color	Clear Blue Liquid
pH - 1% Solution	1.0+/-0.05
Specific Gravity	
Weight per Gallon	
Wetting Ability	
Odor	Pungent (Acid)
Rinsing	• • • •
Foam	Slight